

The adhesives below have been tested and approved by the respective manufacturers for installation of the floorMuffler® underlayments. Diversified Industries has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use.

Manufacturer	ADHESIVE: <i>Underlayment to Substrate</i>	ADHESIVE: <i>Engineered Wood to Underlayment</i>	ADHESIVE: <i>LVT Tile/Plank to Underlayment</i>	TROWEL SIZE
--------------	---	---	--	-------------

**DriTac Adhesives: p: 800-394-9310; w - www.dritac.com**

DriTac	7800 Supreme Green	7700 Easy Clean 4n1	Eco-5900 MegaBond	*
DriTac	-	7400 Easy Spread	Eco-5700 StrongBond	*
DriTac	-	7300 SureBond	Eco-6200	*
DriTac	-	7800 Supreme Green	Eco-5500	*

**Taylor Adhesives: p: 800-868-GLUE; w: www.wftaylor.com**

Taylor Adhesives	2071	2071	2091	*
Taylor Adhesives	2091	-	2098	*
Taylor Adhesives	2098	-	MS Plus Resilient	*
Taylor Adhesives	MS Plus Resilient	-	-	*

**Mapei Adhesives: p: 800-992-6273; w: www.mapei.com/us**

Mapei	Eco 885	UltraBond ECO 962	UltraBond 885	*
Mapei	APAC 620	-	APAC 620	*
Mapei	UltraBond Eco 350	-	UltraBond Eco 350	*
Mapei	UltraBond Eco 360	-	UltraBond Eco 360	*
Mapei	UltraBond Eco 373	-	UltraBond Eco 373	*
Mapei	APAC 584	-	APAC 584	*
NAA Adhesive	Ever Bond TPSA Plus	-	Ever Bond TPSA Plus	*
NAA Adhesive	Ever Bond PSA Super	-	Ever Bond PSA Super	*

**Franklin Adhesives: p: 800-487-4583; w: www.franklinadhesivesandpolymers.com**

Franklin Adhesives	Titebond 670	Titebond 801	Titebond 670	*
Franklin Adhesives	Titebond 801	Titebond 811	Titebond 780	*
Franklin Adhesives	-	Titebond 821 - Step	-	*
Franklin Adhesives	-	Titebond 771- Step	-	*

**Bostik Adhesives: p: 800-7-BOSTIK; w: www.bostik-us.com**

Bostik Adhesives	GreenForce	GreenForce	LVT-Lock+	*
Bostik Adhesives	Bostik's BEST	Bostik's BEST	-	*
Bostik Adhesives	Pro-MSP	Pro-MSP	-	*
Bostik Adhesives	Pro-Cure	Pro-Cure	-	*
Bostik Adhesives	EFA+	EFA+	-	*

**XL Brands: p: 706-272-5807; w: www.xlbrands.com**

XL Brands	Stix 2230	-	Stix 2230	*
-----------	-----------	---	-----------	---

\* ALWAYS speak to respective adhesive manufacturer directly for proper trowel recommendations.

Manufacturer	ADHESIVE: <i>Underlayment to Substrate</i>	ADHESIVE: <i>Engineered Wood to Underlayment</i>	ADHESIVE: <i>LVT Tile/Plank to Underlayment</i>	TROWEL SIZE
--------------	---	---	--	-------------

STAUF USA: p: 866-GLUE USA; w: <http://www.staufusa.com>

STAUF	BCS-827	AEM-852	UVF-867	*
STAUF	-		AEM-852	*
STAUF			PSA-832	*
STAUF			D737	*
STAUF			LVP-777	*

\* ALWAYS speak to respective adhesive manufacturer directly for proper trowel recommendations.